# DO NOT tamper with or cover smoke alarms



Fire Risk Management Ur

**Never** try to change or remove battery from Green Band smoke alarms.

This is the Department of Human Services approved smoke alarm.

In an Emergency telephone "000" For Police, Fire Brigade or Ambulance

240V Smoke Alarm with built in self-charging non-removable Battery

# GREEN **POWER** LIGHT

Indicates power supply to unit.


This should be lit when **power** to your house is available.

### **HUSH BUTTON**

In case of a false Alarm, press the HUSH Button.

The smoke alarm will be silenced for 10 Minutes.

The smoke alarm will then reset itself.



# **TEST BUTTON**

Press and hold **TEST**Button to perform
a self test. It will
make a "beep, beep,
beep" sound.

# Monthly testing recommended

Please call **131172** to report any problems with your smoke alarm e.g. if it fails to operate when testing.

REMEMBER: IF YOUR SMOKE ALARM SOUNDS AND YOU KNOW IT IS A FALSE ALARM, OPEN THE DOORS AND WINDOWS OR WAVE A TOWEL/CARDBOARD UNDER THE ALARM TO MOVE SOME CLEAN AIR THROUGH THE ALARM.

IF THERE IS A FIRE IN YOUR HOME EVACUATE AND CALL TRIPLE '000'.

© Copyright State of Victoria 2013
Authorised by the Victorian Government
50 Lonsdale St, Melbourne.
Published by DHS Fire Risk Management Unit
Printed on sustainable paper
May 2013 [0230912]





